



EXPLODED PARTS LISTING

No.	Description	Item						
1	Stabilizer Flybar Weight	EFLH2219B	20	Inner Shaft Main Gear Retaining Collar	EFLH2211	38	250mAh 1-Cell 3.7V Li-Po	EFLB2501S
2	Stabilizer Flybar Linkage	EFLH2219B	21	Landing Gear, Front	EFLH2522F	39	Landing Gear, Rear	EFLH2522R
3	Stabilizer Flybar Seesaw	EFLH2219B	22	Screw M1.2x2.5	EFLH2211	40	Landing Gear, Rear	EFLH2522R
4	Upper Rotor Blade	EFLH2221	23	Pushrod Set	EFLH2518	41	Landing Gear, Rear	EFLH2522R
5	Stabilizer Flybar	EFLH2219B	24	Pushrod Set	EFLH2518	42	Landing Gear, Rear	EFLH2522R
6	Stabilizer Flybar Weight	EFLH2219B	25	Control Arm Set	EFLH2503	43	Landing Gear, Rear	EFLH2522R
7	Inner Shaft/Hub	EFLH2212	26	Screw M1.2x4	EFLH2503	44	Main Frame, Rear	EFLH2524R
8	Inner Shaft/Hub	EFLH2212	27	Internal Control Linkage Set	EFLH2502	45	Pushrod Set	EFLH2518
9	Bushing	EFLH2213	28	Internal Control Linkage Set	EFLH2502	46	Motor with Pinion, Counterclockwise	EFLH2510
10	Bushing Holder	EFLH2213	29	Internal Control Linkage Set	EFLH2502	47	Canopy Mounting Grommets	EFLH3021
11	Lower Rotor Head	EFLH2217	30	Pushrod Set	EFLH2518	48	Motor with Pinion, Counterclockwise	EFLH2510
12	Lower Rotor Blade	EFLH2220	31	Control Arm Set	EFLH2503	49	Screw M1.2x1.8	EFLH2217
13	Inner Swashplate	EFLH2516	32	Replacement Servo Mechanics	EFLH1066	50	Screw M1.2x5	EFLH2220
14	Swashplate Bearing	EFLH2516	33	Replacement Servo Mechanics	EFLH1066	51	Motor with Pinion, Clockwise	EFLH2509
15	Lower Swashplate	EFLH2516	34	5-in-1 Control Unit, Receiver/ Servo/ESCs/Mixer/Gyro	EFLH2501	52	Lower Rotor Head and Linkage Set	EFLH2217
16	Outer Shaft Retaining Collar	EFLH2214	35	Screw M0.8x2.5	EFLH2501	53	Replacement LED Set (4): Tandem	EFLH2504
17	Main Frame, Front	EFLH2524F	36	Internal Control Linkage Set	EFLH2502			
18	Outer Shaft Main Gear	EFLH2213	37	Body/Canopy	EFLH2522			
19	Inner Shaft Main Gear	EFLH2211						